



M-Fog 1000,
M-Fog 1500,
M-Fog 2500
fog machine

Musikhaus Thomann

Treppendorf 30

96138 Burgebrach

Germany

Telephone: +49 (0) 9546 9223-0

E-mail: info@thomann.de

Internet: www.thomann.de

11.06.2015, ID: 355877, 355990, 355991

Table of contents

1	General information.....	5
1.1	Further information.....	6
1.2	Notational conventions.....	7
1.3	Symbols and signal words.....	7
2	Safety instructions.....	10
3	Features.....	16
4	Installation.....	17
5	Starting up.....	20
6	Connections and operating elements.....	22
7	Operating.....	25
7.1	Time-controlled operation.....	27
7.2	Function in 'DMX' mode.....	28
8	Technical specifications.....	31
9	Troubleshooting.....	34

10 Cleaning..... 36

11 Protecting the environment..... 38

1 General information

This manual contains important instructions for the safe operation of the unit. Read and follow the safety instructions and all other instructions. Keep the manual for future reference. Make sure that it is available to all those using the device. If you sell the unit please make sure that the buyer also receives this manual.

Our products are subject to a process of continuous development. Thus, they are subject to change.

1.1 Further information

On our website (www.thomann.de) you will find lots of further information and details on the following points:

Download	This manual is also available as PDF file for you to download.
Keyword search	Use the search function in the electronic version to find the topics of interest for you quickly.
Online guides	Our online guides provide detailed information on technical basics and terms.
Personal consultation	For personal consultation please contact our technical hotline.
Service	If you have any problems with the device the customer service will gladly assist you.

1.2 Notational conventions

This manual uses the following notational conventions:

Letterings

The letterings for connectors and controls are marked by square brackets and italics.

Examples: *[VOLUME]* control, *[Mono]* button.

Cross-references

References to other locations in this manual are identified by an arrow and the specified page number. In the electronic version of the manual, you can click the cross-reference to jump to the specified location.

Example: See ↗ *'Cross-references'* on page 7.

1.3 Symbols and signal words

In this section you will find an overview of the meaning of symbols and signal words that are used in this manual.

Signal word	Meaning
DANGER!	This combination of symbol and signal word indicates an immediate dangerous situation that will result in death or serious injury if it is not avoided.
WARNING!	This combination of symbol and signal word indicates a possible dangerous situation that can result in death or serious injury if it is not avoided.
CAUTION!	This combination of symbol and signal word indicates a possible dangerous situation that can result in minor injury if it is not avoided.
NOTICE!	This combination of symbol and signal word indicates a possible dangerous situation that can result in material and environmental damage if it is not avoided.
Warning signs	Type of danger
	Warning – high-voltage.

Warning signs	Type of danger
	Warning – flammable substances.
	Warning – hot surface.
	Warning – suspended load.
	Warning – harmful or irritating substances.
	Warning – danger zone.

2 Safety instructions

Intended use

This device is intended to be used to produce artificial fog by vaporising fog fluid. Use the device only as described in this user manual. Any other use or use under other operating conditions is considered to be improper and may result in personal injury or property damage. No liability will be assumed for damages resulting from improper use.

This device may be used only by persons with sufficient physical, sensorial, and intellectual abilities and having corresponding knowledge and experience. Other persons may use this device only if they are supervised or instructed by a person who is responsible for their safety.

Safety



DANGER!

Danger for children

Ensure that plastic bags, packaging, etc. are disposed of properly and are not within reach of babies and young children. Choking hazard!

Ensure that children do not detach any small parts (e.g. knobs or the like) from the unit. They could swallow the pieces and choke!

Never let children unattended use electrical devices.



DANGER!

Electric shock caused by high voltages inside

Within the device there are areas where high voltages may be present. Never remove any covers.

There are no user-serviceable parts inside.



DANGER!

Electric shock caused by short-circuit

Do not modify the mains cable or the plug. Failure to do so could result in electric shock/death or fire. If in doubt, seek advice from a registered electrician.



WARNING!

Risk of burns from flammable liquids

The use of flammable liquids in this device may cause severe burns and damage to property.

Always use approved fog fluids. Never fill flammable liquids into the tank of the device.



WARNING!

Risk of burns

The generated fog at the fog nozzle is hot and can cause burns. Occasionally hot fluid drops may escape from the nozzle.

The distance of persons and objects to the fog nozzle must be at least fifty centimetre (1.6 feet).

Do not touch the fog nozzle during and shortly after operation. It becomes very hot and may cause burns even several hours after switching off the device.



WARNING!

Risk of slipping caused by condensation

Fog machines can produce condensation. Do not direct the fog to floors. Floors and surfaces can become slippery by condensed fog.

Check at regular intervals whether it is possible to walk on the floors without a slipping hazard, and, if necessary, remove the condensation.



WARNING!

Health hazard caused by fog fluid handling

Fog fluid does contain glycols complying with the regulations for foodstuffs. However, it may be harmful if swallowed.

Do not induce vomiting. Seek medical advice immediately. Keep fog fluid in a safe place. If the fog fluid comes into contact with eyes rinse thoroughly with water.



CAUTION!

Possible respiratory problems

The device can be operated safely only with the approved fog fluid. The use of other fluids can release toxic gases. Claims for damages caused by the use of non-approved fluids shall be excluded.

Do not create fog in closed or poorly ventilated areas.

Do not expose persons with health problems (such as allergic respiratory conditions, asthma) to artificial fog.



NOTICE!

Risk of fire

Do not cover the device nor any ventilation slots. Do not place the device near any direct heat source. Keep the device away from naked flames.



NOTICE!

Operating conditions

This device has been designed for indoor use only. To prevent damage, never expose the device to any liquid or moisture. Avoid direct sunlight, heavy dirt, and strong vibrations.



NOTICE!

Power supply

Before connecting the device, ensure that the input voltage (AC outlet) matches the voltage rating of the device and that the AC outlet is protected by a residual current circuit breaker. Failure to do so could result in damage to the device and possibly injure the user.

Unplug the device before electrical storms occur and when it is unused for long periods of time to reduce the risk of electric shock or fire.

3 Features

This fog machine is suitable for use in clubs, bars, discotheques, on stages as well as for fire drills.

Special features of the device:

- Control via DMX (3 channels) or the removable control panel
- Suitable for mobile use
- Large liquid container for the fog liquid

4 Installation

Unpack and carefully check that there is no transportation damage before using the unit. Keep the equipment packaging. To fully protect the device against vibration, dust and moisture during transportation or storage use the original packaging or your own packaging material suitable for transport or storage, respectively.

You can install the device standing or hanging. When in use, the device must be mounted at a solid surface or clamped to an approved truss.

Work from a stable platform whenever you install or move the device or when you perform any kind of maintenance. Block access under the work area.



WARNING!

Risk of injury by falling off

Make sure that the installation complies with the standards and rules that apply in your country. Always secure the device with a secondary safety attachment, such as a safety cable or a safety chain.


The carrying capacity of the truss or other mounting must be sufficient for the intended number of devices. Note that the movement of the head may additionally stress the load-bearing structures.

Standing installation

Place the unit on a flat surface. The device must never be operated in a more than 15° tilted position. The device requires 20 cm clearance at the sides and above.

Flying operation

To fasten the unit in flying operation, thread the mounting and safety cables from the truss through the three safety eyes on the housing.



4 3 × safety eye (screw thread M6).

M-Fog 1000, M-Fog 1500, M-Fog 2500

5 Starting up

Establish all connections as long as the unit is switched off. Use the shortest possible high-quality cables for all connections.



NOTICE!


Possible data transmission errors

For error-free operation make use of dedicated DMX cables and do not use ordinary microphone cables.

Never connect the DMX input or output to audio devices such as mixers or amplifiers.


Connections in DMX mode

Connect the DMX input of the device to the DMX output of a DMX controller or another DMX device. Connect the output of the first DMX device to the input of the second one, and so on to form a daisy chain. Always ensure that the output of the last DMX device in the daisy chain is terminated with a resistor ($110\ \Omega$, $\frac{1}{4}\text{ W}$).



M-Fog 1000, M-Fog 1500, M-Fog 2500

6 Connections and operating elements



1	Fog nozzle.
2	Fog fluid container with screw-cap.
3	Carrying handle.
4	3 × safety eye (screw thread M6).
5	Main switch and fuse holder.
6	<i>[DMX INPUT]</i> DMX input.
7	<i>[DMX OUTPUT]</i> DMX output.
8	<i>[Minutes]</i> Rotary control to set the interval between two fog blasts.
9	<i>[Seconds]</i> Rotary control to set the duration of the fog blast.

10	<i>[Volume]</i> Rotary control to set the fog amount per blast.
11	Thumb screws for attaching the removable control panel.
12	On / off switch of the removable control panel.
13	DIP switch for setting the DMX address.

7 Operating

Filling the unit

**NOTICE!****Possible damages caused by unsuitable fog fluid**

Fog liquids not approved by the manufacturer may permanently damage the unit.

Only use the fog fluids listed on www.thomann.de and follow their instructions for use.

First, make sure the unit is switched off.

Open the screw-cap of the liquid container and fill in the fog fluid. Make sure that no fluid is spilled or gets into the device. The easiest way is using a funnel. For the capacity of the containers see  *Chapter 8 'Technical specifications' on page 31.*

Screw the cap firmly back on.

Turning the unit on



NOTICE!

Fire hazard

Do not operate the machine unattended.

Connect the device to the power grid and turn it on with the main switch. The green indicator LED *[Power]* on the control panel lights.

Once the required operating temperature is reached, the green LED *[READY]* on the control panel lights.

When operating, always ensure that there is sufficient fog fluid in the liquid container to avoid no-load running.

Turning the unit off

Turn off the power using the main switch. Transport the device only when it is completely cooled down. To avoid leaking fog fluid during transport, you should transport the device only with empty fluid container.

7.1 Time-controlled operation

The control panel can be detached from the device and used as a wired remote control (controls ↪ *Chapter 6 'Connections and operating elements' on page 22*). For this purpose, loosen the two thumb screws on the control unit.

Turn the control unit on. The green LED [*Output*] and the red LED [*Volume*] light up.

Use the rotary controls [*Minutes*] and [*Seconds*] to set the interval between two fog blasts and the duration of the fog blast. Once the timer is active, the green LED [*TIMER*] is flashing.


Adjust the intensity of the fog blast using the rotary control [*Volume*] as needed.

7.2 Function in 'DMX' mode

Setting the DMX address

Use the DIP switches of the device to set the desired DMX address between 1 and 512 (see the following figure).

DMX Address Set



DMX Add 001



DMX Add 002



DMX Add 003



DMX Add 004



DMX Add 005

.....



DMX Add 512

DMX channel allocation

Channel	Value	Function
1	Blast volume	
	0 ... 10	no fog blast
	11	minimum fog blast
	0 ... 255	maximum fog blast
2	interval between two fog blasts	
	0 ... 10	off
	11	10 s
	12	20 s
	13	30 s
	14	40 s
	...	

Channel	Value	Function
	255	2450 s
3	Fog blast duration	
	0 ... 10	off
	11	10 s
	12	20 s
	13	30 s
	14	40 s
	...	
	255	2450 s

8 Technical specifications

M-Fog 1000

Heater power	1,000 W
Fog output	approx. 240 m ³ /min
Fluid container capacity	2 l
Warm-up time	approx. 4 min
Operating supply voltage	AC 230 V ~, 50 Hz
Fuse	5 mm × 20 mm, 6 A, 250 V, slow-blow
Dimensions (W × H × D)	234 mm × 227 mm × 415 mm
Weight	6 kg

M-Fog 1000, M-Fog 1500, M-Fog 2500

M-Fog 1500

Heater power	1,500 W
Fog output	approx. 320 m ³ /min
Fluid container capacity	2 l
Warm-up time	approx. 7 min
Operating supply voltage	AC 230 V ~, 50 Hz
Fuse	5 mm × 20 mm, 8 A, 250 V, slow-blow
Dimensions (W × H × D)	234 mm × 227 mm × 450 mm
Weight	8 kg

M-Fog 2500

Heater power	2,500 W
Fog output	approx. 470 m ³ /min
Fluid container capacity	6 l
Warm-up time	approx. 10 min
Operating supply voltage	AC 230 V ~, 50 Hz
Fuse	5 mm × 20 mm, 12 A, 250 V, slow-blow
Dimensions (W × H × D)	300 mm × 262 mm × 595 mm
Weight	13 kg

M-Fog 1000, M-Fog 1500, M-Fog 2500

9 Troubleshooting

In the following we list a few common problems that may occur during operation. We give you some suggestions for easy troubleshooting:

Symptom	Remedy
The unit does not work	Check the mains connection and the main fuse.
No response to the DMX controller	1. Check the DMX connectors and cables for proper connection.
	2. Check the address settings and the DMX polarity.
	3. Try using another DMX controller.
	4. Check to see if the DMX cables run near or alongside to high voltage cables that may cause damage or interference to DMX interface circuits.
No fog output	1. Check the fluid level in the fog container.
	2. Switch the device off and check the hose that leads into the fluid container for flow.

If the procedures recommended above do not succeed, please contact our Service Center. You can find the contact information at www.thomann.de.

10 Cleaning



NOTICE!

Possible damages caused by unsuitable cleaning agents

Cleaners not approved by the manufacturer may permanently damage the unit.

Only use the fog machine cleaners listed on www.thomann.de and follow their instructions for use.

Clean the appliance after every 30 operating hours, or if it was not in use for a longer period of time.

Procedure

1. ➤ Make sure that the device is turned off, disconnected from the mains and completely cooled down.
2. ➤ Place the unit in a well ventilated place.
3. ➤ Take the suction hose out of the fluid container of the fog machine and put it into the bottle with the cleaning fluid.
4. ➤ Connect the device to the mains and turn it on with the main switch.
5. ➤ Wait until the required operating temperature has been reached.

- 6.** ➤ Switch the unit to continuous operation and release fog for about 20 seconds.
- 7.** ➤ Put the suction hose back into the fluid container of the fog machine and release fog for another 20 seconds. This rinses the pipes.
 - ⇒ The cleaning is completed.

11 Protecting the environment

Disposal of the packaging material



For the transport and protective packaging, environmentally friendly materials have been chosen that can be supplied to normal recycling.

Ensure that plastic bags, packaging, etc. are properly disposed of.

Do not just dispose of these materials with your normal household waste, but make sure that they are collected for recycling. Please follow the notes and markings on the packaging.

Disposal of your old device



This product is subject to the European Waste Electrical and Electronic Equipment Directive (WEEE). Do not dispose with your normal household waste.

Dispose of this device through an approved waste disposal firm or through your local waste facility. When discarding the device, comply with the rules and regulations that apply in your country. If in doubt, consult your local waste disposal facility.



